COMMAX
SmartHome & Security

MODUM SYSTEM

VIDEOPHONE
AUDIOPHONE
VIDEO PANEL
AUDIO PANEL
DISTRIBUTOR
CCTV
UTP
2 WIRES
4 WIRES
SINGLE HOUSE
SMALL APARTMENT
APARTMENT COMPLEX
GUARD COMMUNICATION
PORTER COMMUNICATION
MULTI ACCESS
CENTRAL MANAGEMENT
TOTAL SECURITY
INTEGRATION
UNIFICATION
EXPANSION

One system for all
requirements.

MODUM SYSTEM FOR ALL DOOR-ENTRY SYSTEM!!

MODUM SYSTEM is a multi functional system which can be used in various door entry and surveillance systems. It has 4.3 / 7 inch MODUM VIDEOPHONE with CCTV MONITORING and total access control through MODUM PANELS and MODUM DISTRIBUTORS to connect to functional modules.

Integration

MODUM SYSTEM PROVIDES NEW DOOR ENTRY SOLUTION BY INTEGRATING VARIOUS DIFFERENT FUNCTIONS :
MODUM VIDEOPHONE can provide CCTV monitoring, Video and Audio Door units that can communicate with other indoor units.
It can be also used with RFID and PIN numbers for access through MODUM PANEL.

Unification

MODUM SYSTEM UNIFIES WIRING ENVIRONMENT :
It is possible to unify using through the exclusive distributor of MODUM SYSTEM even in the different wiring environment such as UTP / 2 WIRES / 4 WIRES.

Expansion

MODUM SYSTEM CAN BE EXPANDED TO MEET ANY REQUIREMENTS :
• Video to Audio modules
• Handset to Hands free type design
• 4.3" to 7" monitor, etc.
• MODUM PANELS: 26 types

QUAD FUNCTION CCTV MONITORING

The MODUM VIDEOPHONE allows for up to 8 CCTV Cameras that can monitor your home as well as common residential areas like the playground, guard post, parking lot, etc. This is the first CCTV Cameras connected to videophones. This now allows users to monitor security blindspots.

4 CCTVs

Playground

Parking lot (1)

Entrance

Lobby

Additional 4 CCTVs

Swimming pool

Parking lot (2)


Guard post

Senior center

MODUM VIDEOPHONE
CMV-70S

7 inch Premium Full-Touch MODUM VIDEOPHONE improves house's interior class. It has enhanced security function of CCTV monitoring and security sensor and can be installed to all door entry environments from a single house to an apartment complex.

CCTV Monitoring & Recording
- Safety check through Quad display videophone
- Up to 8 CCTV cameras and real time monitoring function at your house
- Storing image in Micro SD memory

Alarming for security
- Safety alarm function from interlocked door sensor

2 Door Opening
- 2 door open function through 2 door cameras
- Increasing convenience from one location

Guard Call & Porter Call
- Calling a guard/porter with one button
- Faster communication when assistance needed

CCTV Monitoring! Single/System Dual Application!

MODUM VIDEOPHONE
CMV-43SV / CMV-43S

4.3 inch Standard MODUM VIDEOPHONE improves house's interior class. It has enhanced security function of CCTV monitoring and can be installed to all door entry environments from a single house to an apartment complex.

CCTV Monitoring
- Safety check through videophone
- Up to 8 CCTV cameras and real time monitoring function at your house

2 Door Opening
- 2 door open function through 2 door cameras
- Increasing convenience from one location

Guard Call & Porter Call
- Calling a guard/porter with one button
- Faster communication when assistance needed

x 8

CCTV Monitoring! Single/System Dual Application!

MODUM VIDEOPHONE
CMV-43A

4.3 inch basic MODUM VIDEOPHONE which enhance security function by CCTV monitoring. It can be installed to all door entry environments from a single house to an apartment complex.

CCTV Monitoring
- Safety check through videophone
- Up to 8 CCTV cameras and real time monitoring function at your house

2 Door Opening
- 2 door open function through 2 door cameras
- Increasing convenience from one location

Guard Call & Porter Call
- Calling a guard/porter with one button
- Faster communication when assistance needed

x 8

Usage

OSD

CCTV on screen display

Interphone on screen display

CCTV Monitoring

1 Press the monitor button once

2 Press the Key button once

3 CCTV ch.1 (next channel)

Guard Call

1 Press the Interphone button once

2 Press the GUARD button once

3 You can talk with guard when he answers the call

Porter Call

1 Press the Interphone button once

2 Press the PORTER button once

3 You can talk with porter when he answers the call

MODUM PANEL LINE

1 Look, 2 Sizes, 26 types of MODUM PANELS. It is available for various house types and system environments. With integrated access control features, enjoy your life safely and conveniently.

Access Control

Providing 2ways access control function
• PIN numbers with ten-key
• RFID card

4 Ways Communication

Simple way to call a house
• Direct button call
• Household number call
• Guard call
• Name search

26 Different Options

1 Look , 2 Sizes , 26 types of MODUM PANELS meet all requirements regardless of housing type or system environments

26 types!

Usage

Access Control (PIN number Access)

① Enter the Household Number
② Press Key Button
③ Enter the Household PIN Number
④ Press Call Button

Access Control (RFID Card Access)

① Touch the RFID Card
② Open Lobby

Direct Button Call

① Press the Direct Button Number
② Press Call Button

Household Call

① Press the Household Number
② Press Call Button

Guard Call


① Press the Security Button
② Press the Call Button

Name Search

① Press Searching Button
② Searching the Name by Pressing the Shift Key Button (pressing the page flip button)
③ Press the Call Button

MODUM DISTRIBUTOR

No limitation on the wiring such as UTP / 2 WIRES / 4 WIRES
Connecting modularized distributors with CCTV cameras and FINE VIEW monitors
Providing various options in audio and video systems.

Floor Distributor
CMD-404FU

Floor Distributor
CMD-404F2

Floor Distributor
CMD-204F2

Fine view Distributor
CMD-404CFU

Building Distributor
CMD-101BU

Building Distributor
CMD-101B2

Floor Distributor
CMD-204AF2

Floor Distributor
CCU-204AGF

CCTV Distributor
CMD-104VU

CCTV Camera Connection
Connectable up to 8 channel CCTVs through the CCTV DISTRIBUTOR (4 channels per CCTV DISTRIBUTOR).

CCTV Distributor ×4

CCTV Distributor ×4

Combined Audio & Video
Both Audio & Video phones can be installed in a same building.


Floor Distributor

Floor Distributor

UTP / 2 WIRES / 4 WIRES
Enabling to integrate using MODUM DISTRIBUTORS in different wiring methods such as UTP / 2 WIRES / 4 WIRES without limitation.


UTP

2 Wire 4 Wire

Connectable with FINE VIEW
FINE VIEW DISTRIBUTOR connects COMMAX FINE VIEW products with 26 different MODUM PANELS (visitor monitoring only).

Fine view Distributor

Household
Max. 316 monitors
connectable

2wire

UTP

UTP

UTP   UTP

UTP   UTP

4 Wire   4 Wire

Floor Distributor
Max. 79 floor distributor
connectable

UTP   UTP

UTP   UTP

4 Wire   4 Wire

2wire

UTP

UTP

Building Distributor

UTP

UTP

UTP

UTP   UTP

UTP   UTP

Public Entrance
Up to 99 MODUM
PANELS (including
outside panel)

Common Area
Distance from lobby panel
to last monitor : 300 m

UTP

UTP

Modum System Specification
MODUM DISTRIBUTOR

All UTP

Floor Distributor
CMD-404FU

Power source	DC 24V, 1A (From Building distributor)
Port	4 ports (Connectable with Video Phone up to 4 ea)
Wiring	-Household unit-to-Floor distributor: UTP
	-Building distributor-to-Floor distributor: UTP
	-Floor distributor-to-Floor distributor: UTP
Mount type	Din-Rail Mounted type
Dimension (mm)	106(w)x76(h)x44(d)

F/D

Building Distributor
CMD-101BU

|	
Power source	DC 24V, 1A (Power supply to floor distributor)
Port	4 ports (Connectable with Panel , Guard, Porter, CCTV distributor)
Wiring	-Building distributor to Modum panel: UTP
	-Building distributor-to-Floor distributor: UTP
	-Building distributor-to-CCTV distributor: UTP
	-Building distributor-to-Guard station: UTP
	-Building distributor-to-Porter station: UTP
Mount type	Din-Rail Mounted type
Dimension (mm)	106(w)x76(h)x44(d)

B/D

2 Wire + UTP Combination

Floor Distributor
CMD-404F2

|	
Power source	DC 40V (From Building distributor)
Port	4 ports (Connectable with Video Phone up to 4 ea)
Wiring	-Household unit-to-Floor distributor: UTP
	-Building distributor-to-Floor distributor: 2 wires
	-Floor distributor-to-Floor distributor: 2 wires
Mount type	Din-Rail Mounted type
Dimension (mm)	157(w)x86(h)x59(d)

F/D

Building Distributor
CMD-101B2

|	
Power source	DC 40V, 10A (Power supply to floor distributor)
Port	4 ports (Connectable with Panel, Guard, Porter, CCTV distributor)
Wiring	-Building distributor to Modum panel: UTP
	-Building distributor-to-Floor distributor: 2 wires
	-Building distributor-to-CCTV distributor: UTP
	-Building distributor-to-Guard station: UTP
	-Building distributor-to-Porter station: UTP
Mount type	Din-Rail Mounted type
Dimension (mm)	157(w)x86(h)x59(d)

B/D

All 2 Wire Video

Floor Distributor
CMD-204F2

Power source	DC 40V (From Building distributor)
Port	4 ports (Connectable with Video Phone up to 4 ea)
wiring	-Household unit-to-Floor distributor: 2 wires
	-Building distributor-to-Floor distributor: 2 wires
	-Floor distributor-to-Floor distributor: 2 wires
Mount type	Din-Rail Mounted type
Dimension (mm)	157(w)x86(h)x59(d)

**Building Distributor**
CMD-101B2

Power source	DC 40V, 10A (Power supply to floor distributor)
Port	4 ports (Connectable with Panel , Guard, Porter, CCTV distributor)
Wiring	-Building distributor to Modum panel: UTP
	-Building distributor-to-Floor distributor: 2 wires
	-Building distributor-to-CCTV distributor: UTP
	-Building distributor-to-Guard station: UTP
	-Building distributor-to-Porter station: UTP
Mount type	Din-Rail Mounted type
Dimension (mm)	157(w)x86(h)x59(d)

All 2 Wire Audio

Floor Distributor
CMD-204AF2

Power source	DC 40V (From Building distributor)
Port	4 ports (Connectable with 2 wire Audio phone up to 4 ea)
Wiring	-Household unit-to-Floor distributor: 2 wires
	-Building distributor-to-Floor distributor: 2 wires
	-Floor distributor-to-Floor distributor: 2 wires
Mount type	Din-Rail Mounted type
Dimension (mm)	157(w)x86(h)x59(d)

2 Wire Audio

Floor Distributor
CCU-204AGF

Power source	DC 24V / 3A
Port	4 ports (Connectable with 2 wire Audio phone up to 4 ea)
Wiring	-Modum panel-to -Floor distributor: UTP
	-Household unit-to-Floor distributor: 2 wires
	-Floor distributor-to-Floor distributor: UTP
Mount type	Din-Rail Mounted type
Dimension (mm)	157(w)x86(h)x59(d)

CCTV Distributor

CMD-104VU

Power source	DC 12V, 4A PoD(Power on Distributor)
Port	4 ports (Connectable with CCTV camera up to 4 ea)
Wiring	-CCTV distributor-to-Building distributor: UTP
	-CCTV distributor-to-CCTV cameras: UTP
Mount type	Din-Rail Mounted type
Dimension (mm)	106(w)x76(h)x44(d)

CCTV Cameras

B/D

UTP UTP UTP UTP

UTP

UTP

CCTV Distributor

Connectable Products

CAU-D047TP
(BULLET)

CAD-I4V7TP
(DOME)

Fine View Distributor
(Visitor Monitoring Only)

CMD-404CFU

Power source	DC 24V, 1A
Port	4 ports (Connectable with Fine View Video phone up to 4 ea)
Wiring	-Household unit-to-Floor distributor: UTP
	-Building distributor-to-Floor distributor: UTP
	-Floor distributor-to-Floor distributor: UTP
Mount type	Din-Rail Mounted type
Dimension (mm)	106(w)x76(h)x44(d)

Fineview Video Door phones

F/D

UTP UTP UTP UTP UTP

UTP

Fine View Distributor Connectable Products

CDV-70UM
/ CDV-70U

CDV-72UM

CDV-70KM
/ CDV-70K

CDV-71AM
/ CDV-70A

CDV-70P

CDV-43N

CDV-35U

CDV-35A

COMMON AREA PRODUCTS

CCTV Camera (Bullet) PoD (Power on Distributor)

CAU-D047TP

Power	Power from CCTV distributor
Image sensor	1/3" SONY 960H SUPER HAD II CCD
Minimum Illumination	0.1Lux at F1.2
Resolution	700TV Line high resolution
Lens	3.6mm fixed focus lens
Wiring	CCTV distributor-to-CCTV cameras: UTP
DNR	2D/3D DNR

CCTV Camera (Dome) PoD (Power on Distributor)

CAD-I4V7TP

Power	Power from CCTV distributor
Image sensor	1/3" SONY 960H SUPER HAD II CCD
Minimum Illumination	0.1Lux at F1.2
Resolution	700TV Line high resolution
Lens	2.8mm~12mm varifocal lens
Wiring	CCTV distributor-to-CCTV cameras: UTP
DNR	2D/3D DNR

Porter Phone

AP-3SG (Porter)

Power source	AC 100V, 110V, 220V, 50/60Hz
Mount type	Surface-mounted type
Wiring	Building distributor-to-Porter Phone: UTP
Dimensions (mm)	94(w)x185(h)x38(d)

Guard Station

CDS-2AG

Power source	DC 12V, 1A
Features	• Setting a Floor Distributor -changing a Bldg No./ Household No./PIN number • Paging and calling household • Calling for lobby • Interlocking with unmanned courier system • System setting program
Mount type	Desk type
Wiring	Building distributor-to-Guard Station: UTP
Distance	Max. 100m
Dimensions (mm)	230(w)x200(h)×35(d)

CDS-70MV (SECUMAX Connectable)

|	
Power source	DC 14V/2.1A
Features	• Setting a Floor Distributor -changing a Bldg No./ Household No./PIN number • Paging and calling household • Calling for lobby • Interlocking with unmanned courier system • System setting program
LCD size	7 inch Full touch wide color LED
Mount type	Desktop / Surface-mounted type
Wiring	Building distributor-to-Guard Station: UTP
Dimensions (mm)	361(w)x238(h)x22(65)(d)

MODUM SYSTEM APPLICATION

Single House

Single House (A type)

• Easy installation for a 2 doors house (Front & garage door)
• Support 2 monitors, 2 cameras and 2 interphones

Single House (B type)

• Easy installation for a 2 doors house (Front & garage door)
• Support 2 monitors, 2 cameras
• Intercommunication between 2 monitors

Small Apartment(UTP)

UTP UTP
UTP UTP
F/D
UTP
B/D **CCTV Distributor** CCTV (Max. 4ea)
UTP UTP
Guard Station
UTP
Automatic door

* without Porter

UTP UTP
UTP UTP
F/D
UTP
B/D **CCTV Distributor** CCTV (Max .4ea)
UTP UTP
Porter
UTP
Guard Station
UTP
Automatic door

The best unmanned security system for a small apartment. Supporting up to 316 households and simple door opening with various access ways.

- PIN number
- RFID card
- Direct button call
- Name search
- Guard call
- Porter call

Small Apartment (2 Wire)

2 Wire Video & Audio

• 2 Wire solution for Video and Audio units in a same building
• Apply both systems not only for existed buildings but for new buildins

Apartment Complex

- Interfacing with CCTV, Guard and Porter
- A single integrated control system applying to an apartment complex
- Providing a various configurations for the safety with SECUMAX program

MODUM VIDEO PHONE, VIDEO & AUDIO PANEL

Premium Video Phone

CMV-70S

- CCTV Monitoring & Quad display (only for connecting with MODUM DVR)
- Connectable with 180° Door camera
- Connectable with security sensor
- Guard Call/Porter Call
- Memory storing in Micro SD memory
- Video talk and door lock release enable
- Single House/Apartment Complex convertible
- Expandable up to 2 monitors, 2 door cameras and 2 Interphones

Power source	DC from distributor or AC 110-240V, 50/60Hz
Display	7" inch Full touch wide color LED
Mount type	Surface-mounted type
Wiring	Door camera: UTP or 2 Wires
	Floor Distributor: UTP or 2 Wires
Operating temp.	0℃~+60℃
Dimension (mm)	243(w)×174(h)×33(d)

Standard Video Phone

CMV-43SV / CMV-43S

- CCTV Monitoring
- Guard Call
- Porter Call
- Video talk and door lock release enable
- Compatible with Single House and Apartment Complex
- Expandable up to 2 monitors, 2 door cameras and 2 Interphones

Power source	DC from distributor or AC 110-240V, 50/60Hz
Display	4.3 inch wide color LED
Mount type	Surface-mounted type
Wiring	Door camera: UTP or 2 Wires
	Floor Distributor: UTP or 2 Wires
Operating temp.	0℃~+60℃
Dimension (mm)	174(w)x243(h)x33(d) 243(w)x174(h)x33(d)

Basic Video Phone

CMV-43A

- 4.3 inch LED display
- CCTV monitoring
- 2 Door Opening
- Guard Call / Porter Call

Power source	AC 110-240V, 50/60Hz
LCD size	4.3 inch wide color LED
Mount type	Surface-mounted type
Wiring	Floor distributor: UTP
	Door Camera: UTP
	Door camera: 28m (0.65Ø)
Distance	Interphone: 20m
Operating temp.	0℃~40℃
Dimension (mm)	230(w)×209(h)×27(d)

Crystal MODUM Panel

DRC-703LC/RF1

- 3.5 inch LED display
- Page and call a household unit or a security guard station
- Various verification methods (PIN number and RFID card)
- Expandable up to 99 units of DRC-703 LC/RF1
- Mirror view of a visitor enabled when paging

Power source	DC 12V/1A
Power	Standby: 200mA
Consumption	Maximum: 450mA
Wiring	UTP(Cat. 5e)
Angle of View	Horizontal: 68° Vertical: 55°
RFID card	13.56Mhz (Optional)
Dimension (mm)	244(w)x270(h)x17(43)(d)

Door Camera

DRC-4U (BLUE/WHITE)

DRC-41UN

DRC-40KH/40K

DRC-4G

DRC-4FC

DRC-4CGN2

DRC-4CPN2

MODUM Panel (Video & Audio)

CMP-2BCT
CMP-2BCT/RF1
CMP-4BCT
CMP-4BCT/RF1

- Access Control (PIN number/RFID card)
- 8 button Direct button call (CMP-2BCT)
- 16 button Direct button call (CMP-4BCT)
- Page and call a household unit or a security guard station
- Name searching through 2.4" OLED display

Power source	DC 12V, 1A
Mount type	Built-in (Flush mounted)
RFID card	13.56Mhz (optional)
Display	2.4" OLED display
Image sensor	C-MOS (Pin-hole type)
Angle of view	Horiz.: 47° Vert.: 35°
Lighting	Built-in White LED
Operating temp.	-40℃~+60℃
Dimension (mm)	130(w)x315(h)x12(38)(d)

CMP-2BC
CMP-4BC

- 16 Direct buttons call (CMP-2BC)
- 32 Direct buttons call (CMP-4BC)
- Page and call a household unit

Power source	DC 12V, 1A
Mount type	Built-in (Flush mounted)
Image sensor	C-MOS (Pin-hole type)
Angle of view	Horiz.: 47° Vert.: 35°
Operating temp.	-40℃~+60℃
Dimension (mm)	130(w)x315(h)x12(38)(d)

CMP-2BX
CMP-4BX (EXTENSION PANEL)

- 24 Direct buttons call Extension panel (CMP-2BX)
- 48 Direct buttons call Extension panel (CMP-4BX)

Power source	From main panel
Mount type	Built-in (Flush mounted)
Operating temp.	-40℃~+60℃
Dimension (mm)	130(w)x315(h)x12(38)(d)

DRC-GUM
DRC-12UX (EXTENSION PANEL)

- Access Control (PIN number/ RFID card)
- Page and call a household unit or a security guard station
- Name searching function
- 12 Direct buttons call Extension panel with name plate

Power source	DC 12V, 1A
Mount type	Built-in (Flush mounted)
RFID card	13.56Mhz (optional)
Image sensor	Color C-MOS 1/4inch
Lighting	White LED x 2
Wiring	UTP (Cat. 5e)
Operating temp.	-40℃~+60℃
Dimension (mm)	130(w)x315(h)x12(38)(d)

21

DRC-900LC/RF1

- Vandal-proof Aluminium Die-casting Case
- Hidden Pinhole camera
- IR sensor Type Anti-freezing Buttons
- Endurability in Extreme Cold -40℃
- Registering up to 3 RFID cards per each household
- Security guard station call enabled
- House call by household number

Power source	DC 12V, 1A
Mount type	Flush mounted type
RFID card	13.56Mhz (optional RF function)
Wiring	UTP (CAT. 5e)
Dimension (mm)	136(w)x260(h)x36(d)

CMP-CTS
CMP-CTS/RF1

- Access Control (PIN number/ RFID card)
- Page and call a household unit or a security guard station
- Name searching through 2.4" OLED display

Power source	DC 12V, 1A
Mount type	Built-in (Flush mounted)
RFID card	13.56Mhz (optional)
Display	2.4" OLED display
Image sensor	C-MOS (Pin-hole type)
Angle of view	Horiz.: 47˚ Vert.: 35˚
Lighting	Built-in White LED
Operating temp.	-40℃~+60℃
Dimension (mm)	130(w)x249(h)x12(38)(d)

CMP-2BCS
CMP-4BCS

- 8 Direct buttons call (CMP-2BCS)
- 16 Direct buttons call (CMP-4BCS)
- Page and call a household unit

Power source	DC 12V, 1A
Mount type	Built-in (Flush mounted)
Image sensor	C-MOS (Pin-hole type)
Angle of view	Horizon.: 47˚ Vert.: 35˚
Operating temp.	-40℃~+60℃
Dimension (mm)	130(w)x249(h)x12(38)(d)

CMP-2BXS
CMP-4BXS (EXTENSION PANEL)

- 16 Direct buttons call Extension panel (CMP-2BXS)
- 32 Direct buttons call Extension panel (CMP-4BXS)

Power source	From main panel
Mount type	Built-in (Flush mounted)
Operating temp.	-40℃~+60℃
Dimension (mm)	130(w)x249(h)x12(38)(d)

MODUM AUDIO PHONE, AUDIO PANEL

Audio Phone

AP-2SAG

- 2 wire connection with non-polarity from a floor distributor
- Talk with a visitor and door release capability

Power source	24V (From floor distributor)
Wiring	2 wires with non-polarity
Distance	100m (0.65Ø)
Operating temp.	0℃~+40℃
Dimension	70(w)x210(h)x60(d)

MODUM Panels (Audio)

CMP-2BAT
CMP-2BAT/RF1
CMP-4BAT
CMP-4BAT/RF1

- Access Control (PIN number/RFID card)
- 8 Direct buttons call (CMP-2BAT)
- 16 Direct buttons call (CMP-4BAT)
- Page and call a household unit or a security guard station
- Name searching through 2.4" OLED display

Power source	DC 12V, 1A
Mount type	Built-in (Flush mounted)
RFID card	13.56Mhz (optional)
Operating temp.	-40℃ ~ +60℃
Dimension (mm)	130(w)x315(h)x12(38)(d)

CMP-2BA
CMP-4BA

- 16 Direct buttons call (CMP-2BA)
- 32 Direct buttons call (CMP-4BA)
- Page and call a household unit

Power source	DC 12V, 1A
Mount type	Built-in (Flush mounted)
Operating temp.	-40℃~+60℃
Dimension (mm)	130(w)x315(h)x12(38)(d)

CMP-2BX
CMP-4BX (EXTENSION PANEL)

- 24 Direct buttons call (CMP-2BX Extension panel)
- 48 Direct buttons call (CMP-4BX Extension panel)

Power source	From main panel
Mount type	Built-in (Flush mounted)
Operating temp.	-40℃~+60℃
Dimension (mm)	130(w)x315(h)x12(38)(d)

CMP-ATS
CMP-ATS/RF1

- Access Control (PIN number/ RFID card)
- Page and call a household unit or a security guard station
- Name searching through 2.4" OLED display

Power source	DC 12V, 1A
Mount type	Built-in (Flush mounted)
RFID card	13.56Mhz (optional)
Display	2.4" OLED display
Operating temp.	-40℃~+60℃
Dimension (mm)	130(w)x249(h)x12(38)(d)

CMP-2BAS
CMP-4BAS

- 8 Direct buttons call (CMP-2BAS)
- 16 Direct buttons call call (CMP-4BAS)
- Page and call a household unit

Power source	DC 12V, 1A
Mount type	Built-in (Flush mounted)
Operating temp.	-40℃~+60℃
Dimension (mm)	130(w)x249(h)x12(38)(d)

CMP-2BXS
CMP-4BXS (EXTENSION PANEL)

- 16 Direct buttons call
- Extension panel (CMP-2BXS)
- 32 Direct buttons call Extension panel (CMP-4BXS)

Power source	From main panel
Mount type	Built-in (Flush mounted)
Operating temp.	-40℃~+60℃
Dimension (mm)	130(w)x249(h)x12(38)(d)

INSTALLATION

UTP
UTP
UTP
UTP
F/D
UTP
B/D **CCTV Distributor** CCTV (Max .4ea)
UTP UTP
UTP Porter
UTP Guard Station
3
Automatic door

1. Modum Panel Wire Connection

10 pin connector **UTP cable**

2. Building Distributor Wire Connection

Floor Distributor

CCTV Distributor

UTP cable **4 pin connector**

3. Porter & Guard Wire Connection

Porter Phone

Guard Station

INSTALLATION

UTP UTP

UTP UTP

F/D

UTP

B/D **CCTV Distributor** CCTV (Max .4ea)

UTP UTP

UTP Porter

UTP Guard Station

3

Automatic door

nth Floor

2nd Floor

4. Floor Distributor To Floor Distributor Wire Connection

5. Video Phone To Floor Distributor Wire Connection

Videophone

Building Distributor (previous page)

Connecting board (Accessory)

INSTALLATION

6. CCTV Camera To CCTV Distributor Wire Connection

SETTING

[PIN Number Setting] by MODUM PANEL Program

1. Press Program Button (K)

UP

↓

Enter Prog. No.
⬚ _ _ _ _ _ _

2. Press "20" (Program No.)

2 0

↓

Enter Prog. No.
⬚ _ _ _ _ 2 0

3. Press Call Button

ENTER

↓

Enter Household
🏠 _ _ _ _ _ _

4. Enter House Number

1 0 1

↓

Enter Household
🏠 _ _ _ 1 0 1

5. Press Call Button

ENTER

↓

Existing Pin Number
🔑 _ _ _ _ _ _

6. Enter Previous House Pin Number
(Factory Default PIN Number)

1 2 3 4

↓

Existing Pin Number
🔑 1 2 3 4

7. Press Call Button

ENTER

↓

New Pin Number
🔑 _ _ _ _ _ _

8. Enter New House Pin Number

6 0 3 9

↓

Existing Pin Number
🔑 6 0 3 9

9. Press Call Button

ENTER

↓

COMMAX
Welcome!

[RF Card Key Setting] by MODUM PANEL Program

1. Press Program Button

↓

Enter Pin Number
🔑 _ _ _ _ _ _

2. Enter Management Pin Number
(Factory Default PIN Number)

4 3 2 1

↓

Existing Pin Number
🔑 * * * *

3. Press Call Button

ENTER

↓

Enter Prog. No.
⬚ _ _ _ _ _ _

4. Enter Program Number

1 0

↓

Enter Prog. No.
⬚ _ _ _ _ 1 0

5. Press Call Button

ENTER

↓

Prog. No. 10
Register RF Card
Total Card: 0001

6. Place the Card Here

CARD

↓

Prog. No. 10
Register RF Card
Total Card: 0002

Newly Registered Card:
The number of the registered
card increases

Prog. No. 10
Register RF Card
Total Card: 0001

Already Registered Card:
The number of the registered
card does not change

7. Press the Cancel Button "X"
to Finish Registering

X

↓

COMMAX
Welcome!

SETTING

[Building Number Setting] by MODUM PANEL

1. Press Program Button (P)

Enter Prog. No.

2. Enter Management Pin Number
(Factory Default PIN Number)

$\boxed{4}\ \boxed{3}\ \boxed{2}\ \boxed{1}$

Existing Pin Number

$\star\star\star\star$

3. Press Call Button

ENTER

Enter Prog. No.

4. Enter Program Number (2)

$\boxed{2}$

Enter Prog. No.

_ _ _ _ 2

5. Press Call Button Previous
Building Number is Displayed

ENTER

Prog. No. 02
Set Val: 1234
In Val: _____

6. Enter Management Pin Number

$\boxed{1}\ \boxed{0}\ \boxed{1}$

Prog. No. 02
Set Val: 1234
In Val: 101

7. Press the Call Button and Building
Number Registeration is Complete

ENTER

COMMAX
Welcome!

SETTING

[Household Number AUTO Setting] by Floor Distributor

※ Just DIP Switch setting of each F/D, household numbers are defined automatically
※ No Needed Setting in One Building, (Plug and play for Guard, Porter)

F/D DIP Switch Setting

Step 6 — 79th Floor (CMD-404FU)

1 2 3 4 5 6 7 8
OFF
ON

313   314   315   316

Step 5 — 3rd Floor (CMD-404FU)

1 2 3 4 5 6 7 8
OFF
ON

9   10   11   12

Step 4 — 2nd Floor (CMD-404FU)

1 2 3 4 5 6 7 8
OFF
ON

5   6   7   8

1   2   3   4

Step 3 — 1st Floor (CMD-404FU)

1 2 3 4 5 6 7 8
OFF
ON

LINE1 LINE2 LINE3 LINE4
IN   OUT
CMD – 404FU

Step 2 — B/D (CMD-101BU)

1 2 3 4 5 6 7 8
OFF
ON

Step 1

CMD-404FU References

MANUAL / AUTO   DEVICE ID
   2nd digit   1st digit
1   2 3 4   5 6 7 8
OFF
ON

※ No. 1 (Select MANUAL /AUTO): OFF=MANUAL/ON=AUTO
No. 2 ~ 4 (Select ID: 2nd digit): Consist of BCD code
No. 5 ~ 8 (Select ID: 1st digit): Consist of BCD code

※ Select 'Auto Mode'
1. Auto Mode (ON): If No. 1 switch is on while the device is booting, it will be operated with Auto mode. Household number will be allocated automatically in order by previously set ID number of lobby phone.

SETTING

[Household Number MANUAL Setting] by Floor Distributor

※ In Manual mode, the installer has to set each household number. But any digit can be used according to the customer's needs like 101,102,103...

※ Plug and play for Guard, Porter

Step 7 — After setting floor distributor please keep setting a household number by Modum panel or Guard station. You can choose only one method (next page).

F/D DIP Switch Setting

Step 6 — 79th Floor (CMD-404FU) — 7901 7902 7903 7904

Step 5 — 3rd Floor (CMD-404FU) — 301 302 303 304

Step 4 — 2nd Floor (CMD-404FU) — 201 202 203 204

Step 3 — 1st Floor (CMD-404FU) — 101 102 103 104

Step 2 — B/D (CMD-101BU)

LINE1 LINE2 LINE3 LINE4
IN   OUT
CMD – 404FU

Step 1

CMD-404FU References

MANUAL / AUTO   DEVICE ID
2nd digit   1st digit

1 2 3 4 5 6 7 8
OFF
ON

※ No. 1 (Select MANUAL /AUTO): OFF=MANUAL/ON=AUTO
No. 2 ~ 4 (Select ID: 2nd digit): Consist of BCD code
No. 5 ~ 8 (Select ID: 1st digit): Consist of BCD code

※ Select 'Manual mode'
1. Manual Mode (OFF): If No. 1 switch is off while the device is booting, it will be operated with Manual mode. From lobby phone, you can set the Bldg No. or household No. by yourself.

SETTING

## [Household Number MANUAL Setting] by MODUM PANEL

1. Press Program Button

Enter Pin Number
🔑 _ _ _ _ _ _

2. Enter Management Pin Number
   (Factory Default PIN Number)

4 3 2 1

Existing Pin Number
🔑 ✱✱✱✱

3. Press Call Button

Enter Prog. No.
▭ _ _ _ _ _ _

4. Enter Program Number

2 3

Enter Prog. No.
▭ _ _ _ _ 2 3

5. Press Call Button

Prog. No. 23
Sour: _ _

6. Enter Program Number

9 9

Enter Prog. No.
▭ _ _ _ _ 9 9

7. Press Call Button

Prog. No. 99
Sour:

8. Press the Cancel Button "X"
   to Finish Registering

X

COMMAX
Welcome!

9. Press Program Button

Enter Pin Number
🔑 _ _ _ _ _ _

10. Enter Management Pin Number

4 3 2 1

Existing Pin Number
🔑 ✱✱✱✱

11. Press Call Button

Enter Prog. No.
▭ _ _ _ _ _ _

12. Enter Program Number

3 6

Enter Prog. No.
▭ _ _ _ _ 3 6

13. Press Call Button

Prog. No. 36
Sour: _ _

14. Press Call Button

Prog. No. 36
Sour: 1

* Enter Module ID ex) 1

15. Press [UP] [DOWN] Button and

Searching the information
Want to change

Terminal No.   1
Sour: 9700-0001
M01   P: 1234 H: 1234
        _ _

16. Press the Setting Information
   (If you want to set terminal
   Number 1 by 101 (household
   number), 3690 (password) and
   2 (lobby ID)

   *M01 : Lobby ID / P: pin No.
    H: household No.

Terminal No.   1
Sour: 9700-0001
M02   P: 3690 H: 0101
        _ _

17. Press Program Button

COMMAX
Welcome!

SETTING

[Household Number MANUAL Setting] by Guard Station

1. Press Program Check Button

    Program Check

    �current

    ↓

    ```
    Password -           ■
    ```

2. Enter the Password "9999"

    ⑨ ⑨ ⑨ ⑨

    ↓

    ```
    Password -      ＊＊＊＊
    ```

3. Press Program Button

    Program

    ↓

    ```
    Program -            ■
    ```

4. Press ▶ Button 6 times

    →

    ↓

    ```
    Floor Up
    Pr05        0000-000■
    ```

5. Enter Floor Distributor Code

    9700

    ↓

    ```
    Floor Up
    Pr05        0000-970■
    ```

6. Press Program Button

    Program

    ↓

    ```
    Floor Up
    Pr05       9700-    ■
    ```

7. Enter Floor Distributor ID

    01

    ↓

    ```
    Floor Up
    00/32      97000-  01
    ```

8. Press Program Button

    Program

    ↓

    ```
    Terminal  xx        MM
    xxxx-xxxx     PPPP
    ```

9. Press ▶ Button and Searching the Port

    →

    ↓

    ```
    Terminal  01        01
    0101-0001   1234
    ```

    ```
    Terminal  02        01
    0101-0002   1234
    ```

10. Press Program Button

    Program

    ↓

    ```
    Terminal  02        01
    ■101-0002   1234
    ```

11. Press the Household Information (Building No. / Household No. / Pin Number)

    101-102 / 1234

    ```
    Terminal  02        01
    ■101-0002   1234
    ```

12. Press Remote Control Button

    Remote Control

    ↓

    ```
    Floor Down
    00/32       9701-0001
    ```

SECUMAX

COMMAX SECUMAX Program is the software that can control integrating apartment complex. Guarantee the security by integrating controls of various functions such as access information, visitor checking/registering and parking record.

Register Information

Register, inquire and delete resident's RF-Card, resident's car(Option), fingerprints (Option). Possible to save those who entered, entrance method and entrance time and to inquire and print the information.

Alarm Functions

When alarm goes off in an emergency, the administrator can check the residence where the emergency occurred through the use of voice. Figure out when the alarm went off and stopped. Print alarm information. Make an emergency contact when the alarm was confirmed (SMS - Option).

Common Entrance Control

If common entrance needs to stay open for a long time due to a move or for other reasons, the entrance can be shut or opened through the use of PC. The state of the common entrance can be checked.

Parking Management Control

Possible to operate by connecting to parking Systems. It checks the state of each residence device and communications.

SECUMAX

1. System requirements

- Processor: Pentium-4 or higher
- Operating system: Windows 2000/XP (Windows 2000 recommended)
- Memory: 512MB or more (the more memory, the higher performance)
- Hard disk: SCSI - 80GB or more
- Security device: MDC-201PC
- Communication: RS-232C MultiPort (8 Port)
- Monitor: VGA resolution or higher (1024 X 786) (17-inch monitor recommended)
- CD-ROM or DVD-ROM drive
- Microsoft mouse or compatible pointing device
- PC speaker

Caution: If a new SecuMax is installed, all previous data might be lost, so make sure to back up important files.

2. System Device Install (Security device-MDC201PC)

- Product overview
  - It reads RF-Card information, register it with SecuMax3 and implement inquiry.
  - It works as a security key of SecuMax3.
  - It can register card information with DRC at a high speed.
  - It can supply power at will at AC 100V to 220 V
  - It checks activity and communication state of devices through the use of an LED.

- Definition of product functions
  - It can check the current activity state of devices through a blinking LED.

1) POWER LED: On – Power supply
                      Off – Suspension of power supply
2) RUN LED: If it blinks, it means that it is in normal operation.
3) CARD LED: If the card is read or if the PC implements authorization, it blinks.
4) HOST LED: If transmission is implemented from PC to DRC line, it blinks.
5) DRC LED: If transmission is implemented from DRC to DRC line, it blinks.

  - It can communicate to a PC being connected to multiport.

1) It transmits data to DRC through high speed communication to a PC being connected to multiport

2) It connects to multiport and communicates to a PC to send and receive RF-Card data and an authorization code.

3. System Device Connection

  - The multiport connects to 25 pins, and each device connects to 9 pins.
  - The multiport consists of Com 3 through Com10 in the order of connection to the computer.
  - The device connected to the multiport is connected to the console and MDC.
  - Com 3 of the multiport is connected to the MDC "card" and used as an RF-Card input and security key.
  - Com 4 of the multiport is connected to the DRC of the MDC and communicates
    to a DRC device at a high speed to download the RF-Card information and the residence card information.
  - Com 5 of the multiport is connected to the guard station to implement a long-distance communication and send and receive various data.
  - The length of lines should be 15 meters or shorter.
  - Other Com ports are used to communicate to parking, home delivery and security companies.

Multiport (8 port)

Com 3	
1	25 Pin
Com 4	
2	25 Pin
Com 5	
3	25 Pin
Com 6	
4	
Com 7	
5	
Com 8	
6	
Com 9	
7	
Com 10	
8	

Direct connection to computer

Console — 9 Pin

CDS-70MV

DRC   Card — 9 Pin

MDC-201PC

COMMAX

COMMAX Co., Ltd.
494, Dunchon-daero, Jungwon-gu,
Sungnam-si, Gyunggi-do, 462-806, Korea

Phone +82-31-7393-540~550
Fax +82-31-731-2133
Web www.commax.com

GOOD DESIGN

iF product design award 2014

reddot award 2014
winner

INTERNATIONAL DESIGN
EXCELLENCE AWARDS '14

DESIGN AWARD