How to upgrade the DVR

Notice :1.Make sure the USB flash not be infected by virus or format it.

2.Restore default parameter and factory setting one time.

3.Be make sure corresponding of the DVR channel with upgrade file.

4.Must be not power off during the upgrading.

Step1:Format the USB flash.

1.Please prepare for an USB flash and format it with FAT32.

2.Copy the upgrade file to root folder of the USB flash.

Step2:Restore the DVR

1.Log in the DVR and click main menu.

2.Click System Setup   *3.Click Default*

4.Please check the option of the red underline and click Confirm.The DVR will restart automatically after restoring.

5.Please log in again. Following Step2 to enter into the Default desktop ,check the Select All option and click Confirm.

Step3:Upgrade the DVR

1.Plug the USB flash into the DVR

2.Log in again and go into the main menu,click the Advance Option

3.Click Upgrade

4.Select the upgrade file and click Upgrade.

5.Click Confirm

6.Please wait for a moment until showing to upgrade success,and the DVR will restart automatically.

Finish.